

Basic steps for success with Prettau Bridge when starting with an approved existing hybrid prosthesis

Appointment one- Take new final open tray connected impression. Counter model impression. Blu-Mousse bite registration with approved hybrid in place. Photos. Duplicate existing hybrid using "box technique:"

Supplies:



- 1) Paint PVS adhesive on top and bottom of denture.retainer box



- 2) Express PVS impression material onto bottom of denture/retainer box



- 3) Seat Hybrid



- 4) Fill voids with additional impression material and let set



- 5) Clean excess material around periphery of box and ensure box can be closed



6) Paint impression material and hybrid with Vaseline



7) Express impression onto top of denture/retainer box and over exposed hybrid surface



8) Express extra material over hybrid



9) Close box, secure with rubber band and let set



10) Remove Hybrid and send box to lab with case



Request from lab verification jig and screw retained wax set up



Try in and radiograph of verification jig, and try in of screw retained wax set up.

Request PMMA screw retained temporary based on screw retained was tryin. If major modifications are needed to wax try in then do one more try in and send photos of try in and possibly new bite



PMMA delivery-Verification jig will be used to seat multi unit abutments if needed AND for a soft tissue pickup around implants.

Request Final Prettau Bridge



Delivery of final Prettau Bridge